



AdMore ezLINK

PN: ADM-LINK-001

Wiring Connections

1. Register your HEX ezCAN at www.hexezcan.com
2. Download the ezCAN/CanSmart software
3. Install your ezCan or CanSmart controller on your bike
4. Mount the AdMore Light Bar/Kit and route the cable to an area under the seat
5. Connect the ezLINK pigtail to the AdMore Light Bar using the included terminal block, wire color to wire color.
6. Connect one end of the AdMore ezLINK to the pigtail and the other end to the **WHITE** output (shortest output) of the ezCAN/CanSmart
7. Turn the bike on to ensure the AdMore Light Bar illuminates in tail light mode (50% intensity)
8. Connect to your ezCAN/CanSmart using the supplied usb cable
9. Update the software if prompted (Internet access required)
10. Set the **WHITE** output to “ezBUS” and click “Apply”
11. In the upper right-hand corner, click on the 3 lines and select “ezBUS devices” and scan for ezBUS devices
12. Select “AdMore ezLINK” and click “Close”
13. Finally, test the brake and turn signal functions

Please note:

1. Do not attempt to use the AdMore App before completing all of the above steps
2. Your AdMore Light Kit **cannot** be configured using the ezCAN/CanSmart software! If you are installing an AdMore Light Bar **Pro**, you can configure the Light Bar using the free AdMore CONNECT app (after completing all of the above steps).
